MOZA AirCross 3 Camera Compatibility List（For Firmware 1.1.2）								
Brand	Model	Camera Firmware Version	Cable	Shutter	Record	Focus	Power Supply	Note
FUJIFILM	X-T2		*MSCS-C1	√	√	√	—	Cable need to be purchased separately
	X-T20		*MSCS-C1	√	√	√	—	Cable need to be purchased separately
	X-T3	4.1	*MSCS-C1	√	√	√	—	Cable need to be purchased separately
	X-T4		*MSCS-C1	√	√	√	—	Cable need to be purchased separately
	X-T30		*MSCS-C1	√	√	√	—	Cable need to be purchased separately
	GFX100S		*MSCS-C1	√	√	√	—	Cable need to be purchased separately
	GFX50R		*MSCS-C1	√	√	√	—	Cable need to be purchased separately
SONY	A7S	V3.20	MCSC-Multi/C	√	√	√	—	
			M3C-micro	√	√	√	√	
	A7R		MCSC-Multi/C	√	√	√	—	
	A6600		MCSC-Multi/C	√	√	√	—	
	A1							To be tested
	FX3							To be tested
	A7R4							To be tested
	A6000	V3.21	M3C-micro	√	√	√	√	
	A5100		MCSC-Multi/C	√	√	√	—	
	A6300	V2.01	MCSC-Multi/C	√	√	√	—	
	A6400		MCSC-Multi/C	√	√	√	√	
	A6500	V1.00	MCSC-Multi/C	√	√	√	√	
	A7S2	3.0.0	MCSC-Multi/C	√	√	√	√	
	A7S3		MCSC-Multi/C	√	√	√	√	
	A7R2		MCSC-Multi/C	√	√	√	√	
	A7M3	3.0.0	MCSC-Multi/C	√	√	√	√	
			M3C-type-c	√	√	√	√	
	A7R3		MCSC-Multi/C	√	√	√	√	
	A7R4							To be tested
	A7M2		MCSC-Multi/C	√	√	√	√	
	A7C		M3C-CP	√	√	√	√	Cable need to be purchased separately
	FX3							To be tested
	A9		MCSC-Multi/C	√	√	√	√	
	A9Ⅱ		MCSC-Multi/C	√	√	√	√	To be tested
	RX 100 M6							
	RX 100 M4							
	RX 100 M5		MCSC-Multi/C	√	√	√	—	
Panasonic	GH3		*MCSC-REMOTE	√	√	√	—	Cable need to be purchased separately
	GH4		*MCSC-REMOTE	√	√	√	—	Cable need to be purchased separately
	GH5/GH5S		*MCSC-REMOTE	√	√	√	—	Cable need to be purchased separately
	S1	V2.4（S1H）	M3C-type-c	√	√	√	—	
	S5		M3C-type-c	√	√	√	—	
	GH5	V2.7	M3C-type-c	√	√	√	—	
	GH5S	/	M3C-type-c	√	√	√	—	
Canon	5D2	V2.1.2	USB-MINI	√	√	√	—	
	5D3	V1.6.3	USB-MINI	√	√	√	—	
	5D4	1.2.1	USB-MINI	√	√	√	—	
	6D	.1.1.9	USB-MINI	√	√	√	—	
	6D2	1.0.2	USB-MINI	√	√	√	—	
	60D		USB-MINI	√	√	√	—	
	7D		USB-MINI	√	√	√	—	
	1DX		USB-MINI	√	√	√	—	
	90D		USB-MINI	√	√	√	—	
	7D2		M3C-micro	√	√	√	—	
	70D		USB-MINI	√	√	√	—	
	77D	1.0.2	USB-MINI	√	√	√	—	
	80D	1.0.1	USB-MINI	√	√	√	—	
	EOS R	1.7.0	USB-MINI	√	√	√	—	
	EOS R5	1.2.0	M3C-type-CP	√	√	√	—	Before you start recording, please set up the camera correctly.
	EOS R6	1.3.1	M3C-type-CP	√	√	√	—	Before you start recording, please set up the camera correctly.
Nikon	D850	1.2.0	M3C-micro	√	√	√	—	
	Z5	1.02	M3C-type-C&CP	√	√	√	√	
	Z50	2.0.0	M3C-micro	√	√	√	—	
	Z6	3.1.0	M3C-type-C&CP	√	√	√	—	
	Z6Ⅱ	1.01/1.2.0	M3C-type-C&CP	√	√	√	√	
	Z7	3.2.0	M3C-type-C&CP	√	√	√	—	
	Z7Ⅱ	1.1.0	M3C-type-C&CP	√	√	√	√	