

MOZA Mini-P Expanding & Folding Tutorial

Content

Expanding: [Expanding your Mini-P gimbal, please click and follow the steps as shown.](#)

Folding: [Folding your Mini-P gimbal, please click and follow the steps as shown.](#)

Expanding

1. As shown in the figures below, loosen slide lock, rotate gimbal 180° anticlockwise, then it locks automatically.



2. As shown in the figures below, push ejector pad on Roll arm to unlocked position, move Tilt arm upwards and then fasten Tilt knob.



3. As shown in the figures below, loosen Roll knob, raise Roll arm to keep it out of groove of Pan motor crash pad, push down Pan motor lock and then you are ready to film now.



Folding

1. As shown in the figures below, adjust Roll arm and insert it to groove of Pan motor crash pad, then fasten Roll knob.



2. Push ejector pad on Roll arm to unlocked position first, as shown in the figures below, move Tilt arm backwards to end limit, fasten Tilt knob and then push ejector pad to locked position.



3. As shown in the figure below, rotate Pan arm, place Pan knob at outer side and push up Pan

motor lock.



4. As shown in the figures below, loosen slide lock, rotate gimbal 180° along the direction of slide lock, then it locks automatically



5. Operation of folding Mini-P is completed.

