

MOZA Air 2 Camera Compatibility List

2019.03.25

Gimbal firmware version: V0.4.13

All cameras models listed in the table can be balanced and stabilized on the MOZA Air 2.

AV, LV, TV, ISO, focus, shutter, record and power supply columns indicate camera features that can be accessed via the gimbal.

Camera models similar in size or weight may be compatible, but will not be listed until the next verification by Gudsen MOZA.

Brand	Model	Cable	AV	TV	LV	ISO	Focus	Shutter	Record	Power Supply						
Canon	1DX	M3C-Mini	OK	OK	OK	OK	OK	OK	OK	/						
	5D Mark II	M3C-Mini	OK	OK	OK	OK	OK	OK	OK							
	5D Mark III	M3C-Mini	OK	OK	OK	OK	OK	OK	OK							
	5D Mark IV	M3C-Micro	OK	OK	OK	OK	OK	OK	OK							
	6D Mark II	M3C-Mini	OK	OK	OK	OK	OK	OK	OK							
	EOS R	M3C-Micro+Micro to Type-C adapter	OK	OK	OK	OK	/	OK	OK							
	77D	M3C-Mini	OK	OK	OK	OK	OK	OK	OK							
Sony	RX10 II	M3C-Micro	/					/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	RX10 III	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	RX100M4	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A5100	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A6300	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A6500	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A7S	M3C-Micro						/	OK	/						
		MCSC-Multi						OK	OK	/						
	A7S II	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A7R	M3C-Micro						/	OK	/						
		MCSC-Multi						OK	OK	/						
	A7R II	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A7 II	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A7 III	M10C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A7M3	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	A7R3	M3C-Micro						/	OK	OK						
		MCSC-Multi/C						OK	OK	OK						
		MCSC-Multi						OK	OK	/						
	Nikon	D800						M3C-Micro	OK	OK	OK	OK	OK	OK	OK	/
		D850						M3C-Micro	OK	OK	OK	OK	OK	OK	OK	
		Z6						M3C-Micro+Micro to Type-C adapter	OK	OK	OK	OK	OK	OK	OK	
		Z7						M3C-Micro+Micro to Type-C adapter	OK	OK	OK	OK	OK	OK	OK	
	Panasonic	GH3						MCSC-Remote	/					OK	OK	/
		GH4						MCSC-Remote						OK	OK	
		GH5						MCSC-Remote						OK	OK	